

AIR TANK REPLACEMENT PARTS LIST



IHCT-10

REF. #	PART #	DESCRIPTION	QTY.
1	IH-01	PRESSURE GAUGE	1 PC.
2	IH-02	MANIFOLD / SAFETY CHECK VALVE	1 PC.
3	IH-03	AIR HOSE W/ CHUCK	1 PC.

